


TT-014 Priority Setting

S84NX/S86NX

By default, the SATO S84NX/S86NX print engines are set to accept commands specified by the data stream for various printer settings. You can use the Priority setting to control whether to listen or ignore the data stream commands vs the internal printer settings.

1. With the Printer Offline, go to [Settings] → [Printing] → [Advanced] → [Prioritize]



2. **Commands** – Prioritize the settings through commands
3. **Settings** – Prioritize the settings that are set through the product
4. If connected via LAN, you can also control the [Prioritize] setting via the SATO Webconfig and All-In-One tools. On a device connected to the same network, Type in the printers IP address to browser. Login → User: service Password: “USB Serial#”+service

